

100G QSFP28 to QSFP28 AOC

- • • • •
-
- • • • •

Recommended Operating Conditions

[illegible]

Electrical Specification

100G QSFP28 to QSFP28 AOC

Electrical Specification – Transmitter (EACH LANE)

Electrical Specification – Receiver (each Lane)

1. Power on Initialization Time is the time from when the power supply voltages reach and remain above the minimum recommended operating supply voltages to the time when the module is fully functional.
2. The single ended input voltage tolerance is the allowable range of the instantaneous input signals.

1	Storage Ambient Temperature Range	°C	-40	+85	
2	Powered case Temperature Range	°C	0	+70	

100G QSFP28 to QSFP28 AOC

3	Supply Voltage Range @ 3.3V	V	-0.5	3.6	
4	Relative Humidity (non-condensation)	%	0	85	

[illegible]

100G QSFP28 to QSFP28 AOC

100G QSFP28 to QSFP28 AOC